


**BRIGGS
PRESSURE BALANCE
VALVE**



- Model Numbers:**
1820B
1830B
1821B
1831B
1822B
1832B
1823B
1833B
1810B
1811B
1812B
1813B
1800B
1801B
1802B
1803B

Parts List

* Part Number	Description	* Part Number	Description
1	Indicator Label	22	Throttle Discs (4)
2	Plug Button	23	Balance Chamber
3	Selector	24	Body
4	Washer	25	1/2" Pipe Plug
5	Dial Handle	26	Bonnet Nut
6	Spring	27	Bonnet Seal
7	Stem Guide	28	Bonnet
8	Dial Screw (2)	29	Bonnet Gasket
9	Dial Assembly	30	Stem
10	Gasket	31	Plunger
11	Rough-in Guide	32	Spring
12	Screw	33	Plunger Disc
13	Limit Stop	34	Checkstop
14	Sleeve	35	Bonnet Nut
15	Bonnet	36	Rubber Washer
16	Bonnet Retainer	37	Metal Washer
17	"O" Ring	38	Stem
18	"O" Ring	39	Rubber Disc
19	Washer	40	Checkstop Assembly
20	Spring		
21	Stem		

Repair Kits List

Repair Kits Number	Items Included
800-030	17, 18, 20, 22 (4), 28 (2), 30 (2), 34 (2)
800-031	17, 18, 22 (4), 23
800-032	12, 13, 17, 18, 19, 20, 21, 22 (2)

Repair parts sold only in kit form per above.

* Not listed in parts price list as a standard replacement part.

Available in Kits only