



KITCHEN FAUCETS

NOTE: Refer to chart for correct ORDER NUMBER when ordering replacement parts.

A TWO HANDLE KITCHEN DECK FAUCETS



B TWO HANDLE NEOSTYLE KITCHEN DECK FAUCETS



Plumbing Parts Depot

800-448-8977
www.ppd.biz

Plumbing Parts Depot

610-495-8790

www.ppd1.biz

KEY	PART DESCRIPTION	ORDER NUMBER	MODEL																				
			2100	2100 HDF	2102	2102 OAK*	2102 ROS*	2102 CB BRS	2102 SHP	2102 PB SHP	2109*	2109 HDF*	2110*	2400	2400 HDF*	2402	2402 OAK*	2402 ROS*	2402 CB BRS	2402 SHP	2402 PB SHP		
1.	Screws	RP7527																					
		RP7527 PB																					
2.	Handle Bases w/Screws**	RP15249																					
		RP15249 PB																					
3.	Lever Handles — Crystal	RP15069																					
		— Oak	RP15070 OAK																				
		— Rosewood	RP15070 ROS																				
		— Porcelain	RP15070 POR																				
		— Brass	RP15071																				
4.	Screws	RP15071 PB																					
		RP12490																					
5.	Handles w/Screws	RP12491																					
6.	Handles w/Screws — Wood	RP10107 OAK																					
		RP10107 ROS																					
7.	Screws	RP12492																					
8.	Handles w/Screws — Brass	RP11768 HDF																					
9.	Handles w/Screws — Brass	RP11768 CB BRS																					
10.	Spray & Hose Assembly	RP6077																					
		RP6077 PB																					
11.	Support Assembly	RP6015																					
		RP6015 PB																					
12.	Swivel Aerator	RP2189																					
13.	Aerator	RP330																					
		RP330 PB																					
14.	Aerator — Vandal Resistant	RP246																					
15.	Spout Assembly	RP5650																					
		RP5650 PB																					
16.	Spout Nut	RP6070																					
		RP6070 PB																					
17.	Button Set	RP5692																					
18.	Screws	RP5885																					
19.	Handles w/Buttons & Screws	RP5693																					
20.	Bonnet Nuts	RP6060																					
		RP6060 SB																					
21.	Stem Unit Assembly	RP1740																					
22.	Locknuts	RP6064																					
		RP6064 SB																					
23.	Seats & Springs	RP4993																					
24.	Locknuts	RP6183																					
25.	Coupling Nuts	RP5861																					
26.	Diverter Unit	RP6073																					
27.	O-Rings	RP2085																					
28.	Wrench	RP12508																					
29.	Button Set	RP2412																					
30.	Handles w/Buttons & Screws	RP6062																					
31.	Escutcheon	RP6066																					
		RP6066 PB																					
32.	Gasket	RP6075																					

* Discontinued model
 ☆ Optional lever handles
 ☆☆ Lever handles must be ordered separately to complete assembly

KEY	PART DESCRIPTION	ORDER NUMBER	MODELS		
			2167	2167 PB	2467 PB
1.	Spout Assembly	RP15532			
		RP15532 PB			
2.	Aerator	RP15533			
		RP15533 PB			
3.	Retaining Ring	RP15534			
4.	Bonnet	RP15535			
		RP15535 PB			
5.	Diverter Unit	RP6073			
6.	Screws	RP7527			
		RP7527 PB			
7.	Handles-Cross	RP15081	☆	☆	
		RP15081 PB	☆	☆	☆
8.	Handles-Lever	RP14788	☆	☆	
		RP14788 OAK	☆	☆	
		RP14788 WC	☆	☆	
		RP14788 PB	☆	☆	☆
		RP14788 PB OAK	☆	☆	☆
9.	Bonnet Nuts	RP6060			
		RP6060 SB			
10.	Stem Unit Assembly	RP1740			
11.	Locknuts	RP6064			
		RP6064 SB			
12.	Seats & Springs	RP4993			
13.	Escutcheon	RP15536			
		RP15536 PB			
14.	Gasket	RP15537			
15.	Locknuts	RP6183			
16.	Coupling Nuts	RP5861			
17.	Spray and Hose Assembly	RP6077			
		RP6077 PB			
18.	Support Assembly	RP6015			
		RP6015 PB			
19.	O-Rings	RP7536			

☆ Available handle options