


Eljer


WASHERLESS Two-Handle Centerset Lavatory Faucets




558-1000 558-1001
558-1010 558-1011
558-3010



558-1020



558-1002 558-1003



558-1022 558-1023




558-2010 558-2020

ACRYLIC

BLADE

LIGHT COMMERCIAL



Plumbing Parts Depot
610-495-8790
www.ppd1.biz

DESCRIPTION	PART#	FINISH
1 Plug buttons (1 Hot & 1 Cold)	V6936 V69366	Chrome PB./AB.
2 Handle screw	V7833	
3 Acrylic handle	V7800 V78006	Clear Smoke
4 Plastic blade handle	V7804 V5861	Hot Cold
5 Handle screw	V3966	Chrome
6 Washer	WAS8583ZC WAS8583ZH	Cold Hot
7 Handle	HDL8584C	Chrome
8 Skirt	V3909	
9 Stem adaptor	V3971 V3955	Cold Hot
10 Handle assembly(2)	V3911BG2	Chrome

DESCRIPTION	PART#	FINISH
11 Bonnet	V1814 V18144	for Chr & PB for PB
12 Spacer cover	V3972 V39724 V39726	Chrome Pol. Brass Ant. Brass
13 Spacer	V7835	
14 Control assembly	V6860	
15* Control assembly	V6804	
16* Seal & spring repair kit	V7059	
17 Lift rod assembly	V6805 V68054 V68056	Chrome Pol. Brass Ant. Brass
18 Lift rod hole plug button	V3807	

DESCRIPTION	PART#	FINISH
19 Aerator	V3101 V31014 V31016	Chrome Pol. Brass Ant. Brass
Vandal-proof aerator	V7758	Chrome
20 Parts Bag (2 of each part)	V6809*	
** Pop-up assembly	V7300ELJ V73004 V73006	Chrome Pol. Brass Ant. Brass
** Plastic pop-up assembly	V7750SPB V72904 V72906	Chrome Pol. Brass Ant. Brass

* Parts are for discontinued models or models manufactured before 1/15/92 and are subject to availability.

** Not shown, see page B33 for parts information.


Eljer

WASHERLESS Two-Handle Centerset Lavatory Faucets



558-7010 558-7020
558-7030

PORCELAIN CROSS




558-6000

MEDLEY




558-5010 558-5020
558-5030

VICTORIAN



Plumbing Parts Depot
610-495-8790
www.ppd1.biz



DESCRIPTION	PART#	FINISH
1 Handle screw	V3966 V39664 V39666	Chrome Pol. Brass Ant. Brass
2 Handle adaptor	V3965 V39654 V39656	Chrome Pol. Brass Ant. Brass
3 To order handles, see page B34	-----	
4 Cross handle assy.	V3988BG1 V39884BG1 V39886BG1	Chrome Pol. Brass Ant. brass
5 Plug button	V6940 V69404 V69406	Chrome Pol. Brass Ant. Brass
6 Cross handle screw	V8189	
7 Stem adaptor For Cross handles see NOTE.	V3955 V3971	Yellow(Hot) Green(Cold)

DESCRIPTION	PART#	FINISH
8 Bonnet	V18141	Unplated
9 Control assembly	V6860	
10* Control assembly	V6804	
11* Seal and spring repair kit	V7059	
12 Spacer escutcheon	V3972 V39724 V39726	Chrome Polished Brass Antique Brass
13 Spacer	V7835	
14 Lift rod hole plug button	V3807	Chrome
15 Lift rod assembly	V6805 V68054 V68056	Chrome Polished Brass Antique Brass

DESCRIPTION	PART#	FINISH
16* Wood Lift rod assembly	V3954 V39544 V39546	Chrome Polished Brass Antique Brass
17 Aerator	V3101 V31014 V31016	Chrome Polished Brass Antique Brass
18 Parts bag (2 of ea. part)	V6809	
** Pop-up assembly	V7300ELJ V73004 V73006 V73007ELJ	Chrome Polished Brass Antique Brass Chr./Pol. Br.

* Parts are for discontinued models or models manufactured before 1/15/92 and are subject to availability.

** Not shown, see page B33 for parts information

NOTE: For faucets with porcelain cross handles, use V3955 for hot and cold controls.