



Eljer

WASHERLESS Two-Handle Hi-Style Kitchen Faucets




718-1070 718-1080

ACRYLIC




718-7020 718-7120
718-7030 718-7130

PORCELAIN CROSS




718-6060 718-6080

MEDLEY




718-5020 718-5120
718-5030 718-5130

VICTORIAN



718-2020

LIGHT COMMERCIAL



Plumbing Parts Depot

610-495-8790

www.ppd1.biz

DESCRIPTION	PART#	FINISH
1 Spout assembly	V2028 V20284 V20287	Chrome Pol. Brass Chr. / Pol.Br.
2 Aerator	V3101 V31014	Chrome Pol. Brass
3 Bonnet nut	V2013 V20134	Chrome Pol. Brass
4 Retainer ring	V2015	
5 "O" ring	V2022	
6 Escutcheon(2)	V3957BG2 V39574BG2	Chrome Pol. Brass
7 Spout adaptor	V2018	
8 "O" ring	V1161	
9 Diverter	V1819	
10 Crossover hose	V3835	
11 Plug buttons (1 Hot & 1 Cold)	V6936	
12 Handle screw	V7833	
13 Acrylic handle	V7800	Clear
14 Handle screw	V3966 V39664	Chrome Pol. Brass

DESCRIPTION	PART#	FINISH
15 Handle adaptor	V3965 V39654	Chrome Pol. Brass
16 To order handles, see page B34	-----	
17 Stem adaptor See NOTE for cross handles	V3955 V3971	Yellow(H) Green(C)
18 Cross handle assembly	V3988BG1 V39884BG1	Chrome Pol. Brass
19 Plug button	V6940 V69404	Chrome Pol. Brass
20 Handle screw	V8189	
21 Handle screw	V3966	Chrome
22 Washer	WAS8583ZC WAS8583ZH	Cold Hot
23 Handle	HDL8584C	Chrome
24 Skirt	V3909	
25 Handle assembly-2	V3911BG2	Chrome
26 Bonnet nut	V1814 V18141	Chrome Unplated
27 Control assembly	V6800	
Control assembly	V6804	

DESCRIPTION	PART#	FINISH
Seal & spring repair kit	V7059	
30 Mounting washer	V3410	
31 Mounting nut	V7828	
32 IPS parts bag (2 of each part)	V6643	
33 Spray & hose assembly	V7714 V77144 V3764 V37644	Black w/ Chr. Black w/ P.B. White w/ Chr. White w/ P.B.
34 Hose guide assembly	V7715 V3765 V37654	Chrome w/ Blk. Chrome w/ Wht. P. Brass w/ Wht.
35 Pipe cap	113H1	

These parts are **only** for models manufactured before 1/15/92

NOTE: For faucets with porcelain cross handles, use V3955 for hot and cold controls.